## **LED Wall Sconce**

WS70136

## START FROM HERE

- Make sure **POWER** is **COMPLETELY OFF** at the fuse box
- Have your fixture installed by a qualified licensed electrician
- · Prepare everything in a clear area
- · Wear gloves at all time during this installation
- · Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

**Technical Support:** 1-855-855-8926

## Please Note:

- This Kuzco LED fixture comes with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- Use ELV (Electronic Low Voltage) or TRIAC type of dimmer for dimming application

- 1. Remove the fixture from its original packaging
- 2. Separate the mounting plate (1c) from the canopy (2a) by removing the four screws (2c) with allen key
- **3.** Attach the mounting plate (1c) to the electrical junction box (1a) using the two screws (1d) provided in the hardware package (Note: keep back plate level when mounting to octagon box with leveling marks as guide)
- **4.** Make proper electrical connections (**black** to **hot** "L", **white** to **neutral** "N", **ground** to "**GND**") with wire nuts (**1b**) provided in hardware package
- **5.** Attach canopy (2a) to mounting plate (1c) with screws (2c) using allen key
- **6.** Gently slide LED assembly **(4f)** into glass tube **(4a)** until connector receptacles **(4b)** can be exposed through on glass, secure by installing end caps **(4e)**

