LED Wall Sconce



START FROM HERE

- Make sure POWER is COMPLETELY OFF at the fuse box
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area
- Wear gloves at all times during this installation
- Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

- 1. Remove fixture from its original package
- Separate mounting plate (1c) from canopy backplate (2a) by removing backplate screws (2c)
- **3.** Attach mounting plate **(1c)** to electrical junction box **(1a)** using junction box screws **(1e)** provided in hardware package

Please Note:

- This Kuzco LED fixture comes with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- For dimming, an ELV (Electronic Low Voltage) type of dimmer is required


Œ

- 120V input
- Make proper electrical connections (black to hot "L", white to neutral "N", ground to "GND") with wire nuts (1b) provided in hardware package
- **5.** Attach canopy backplate (2a) to mounting plate (1c) by inserting backplate screws (2c) in threaded holes to get desired orientation (See Illustration 1)
- **6.** Attach fixture (3a) to canopy backplate (2a) with fixture screws (2b)

Illustration 1

0 0

0 0 Æ



19054 28th Avenue Surrey, BC Canada V3Z 6M3 T: 604 538 7162 TF: 1-855 85 KUZCO F: 604 538 7196 W: kuzcolighting.com 20210719